

Proper use of your new Polychute Assembly. 1/28/10

Installing the System

- 1. Remove the system from its storage container near the park sewer inlet.***
- 2. Insert the nozzle in the sewer inlet securely.***
- 3. Open the Gray lever on the side of the nozzle.***
- 4. With the other end of the hose assembly walk back to the RV where the sewer outlet is located.***
- 5. Remove the cap on the coach, then the storage cap on the Polylock fitting.***
- 6. Connect the Polylock fitting over the sewer outlet making sure the unit is in as far as it will go, then turn the outer ring on the Polylock until it stops. About 1.5" of travel to the stop.***

Dumping the Tanks

- 1. Check your installation to be sure the nozzle is open and secure in the park sewer inlet.***
- 2. Open the Black dump valve and allow the tank to fully drain. (See Flushing section)***
- 3. Close the Black valve fully and open the Gray valve (if you're RV is equipped with 2 Gray valves open the Galley first). When the tank is fully drained, close the valve.***

Flushing the Holding Tanks

- 1. Most RVs have a flusher in the Black tank and some have them in the Gray tanks. You should have them in both or all 3 tanks if so equipped.***
- 2. Connect a hose to the coach connection on the side of the RV. Do not use the Fresh water hose used for supplying water to the RV.***
- 3. Turn on the water and fill the Black tank about 2/3rds full before opening the dump valve. Repeat this process until the sight glass in your Polychute system runs clear.***
- 4. Repeat step 2 and 3 with your Gray tank(s).***
- 5. Now is the time to restore the assembly as outlined next.***

Restoring the system for travel

- 1. Make sure all tank dump valves are closed.***
- 2. Remove Polylock fitting connected to the coach and install the protective cap.***
- 3. Walk the hose assembly back to the sewer inlet letting the hose collapse as you get close to the park sewer inlet.***
- 4. Close the Gray lever on the nozzle.***
- 5. Insert the nozzle in the storage container and feed the hose and Polyloc fitting back as well.***
- 6. Put back in the RV.***

If you have any questions or need clarification regarding this procedure please let us know by email service@polychute.com .