



What Happens.

When the valve is closed the magnet on the gate inside the valve is under the magnetic switch. This holds the switch OPEN so the 12 VDC Positive cannot go to the negative post. Result, NO light. When the valve is opened, the magnet leaves the switch, so it closes and the light goes ON!

### How the Light Works

The mag switch is normally closed so the light would remain ON if no magnet was near it.

12/7/2011 DM75-1

