



## Stripped Manual Override Shaft Access Procedure

*The following procedure is needed if the manual override on both sides of the valve have been stripped or broken.*



*Cut the raised donut shaped material from around the override shaft. Be careful not to nick the shaft. A hacksaw blade or dremel tool works fine.*



*Donut removed*



*Vice grips on shaft, donut removed*

*With more shaft exposed use vice grips to rotate the shaft in the direction indicated on the valve body to open the valve.*